

Possible causes to TV reception;

In below average TV reception areas a booster is sometimes required which can at times pick up interference from the Redilight driver and boost it which will interfere with the TV reception.

Things to consider if this interference occurs are;

1. TV aerial cables or booster are too close to a Redilight light driver, within a couple of metres.
2. Coaxial cables running over or near the Redilight light driver.

Solutions;

1. Move Redilight light driver a minimum of 5m away from TV booster.
2. Install a Ferrite core around cable on load side of driver (light fitting cable).



How to install a Ferrite core to cable

Open up the Ferrite core and pass the light fitting cable through twice then close.

See pictures beside and below.

Note: The Ferrite core is installed on the load side of the driver (light fitting cable)

*** If further clarification is needed please call Redilight technical department on 1300 559 986**

